

Ademco via16 PROGRAMMING FORM

THIS PROGRAMMING FORM INCORPORATES SYSTEM ENHANCEMENTS INVOLVING FIELDS *28, *35, *36, *49, *50, *57, *76-91 AND MAY ONLY BE USED TO PROGRAM CONTROLS WITH THOSE ENHANCEMENTS.

FIELD FUNCTION **PROGRAMMED VALUES** [] = Default Value

SYSTEM ARMING (*20-*28)

- *20 MASTER SECURITY CODE Enter 4 digits, 0-9 [4][1][1][0]
- *21 QUICK ARM ENABLE † [0 = no], 1 = yes
- *23 FORCED BYPASS FUNCTION † [0 = no], 1 = yes
- *24 RF RECEIVER HOUSE ID CODE With 4281, enter 01-31 House ID. Otherwise enter [00].
- *28 CONFIRMATION OF ARMING DING † [0 = no], 1 = yes

ZONE RESPONSE PROGRAMMING (*29-*38)

- *29 FIRE SOUNDER TIMEOUT DISABLE † [0 = no], 1 = yes
- *30 ALARM BELL TIMEOUT † 0 = none; [1 = 4 min]; 2 = 8 min; 3 = 12 min

ZONE TYPES FOR PROGRAMMING FIELDS *35-37

0 = Zone Disabled (or Undefined)
 1 = ENTRY/EXIT, Burglary
 2 = not used
 3 = PERIMETER, Burglary
 4 = INTERIOR/FOLLOWER, Burglary
 5 = TROUBLE BY DAY/ALARM BY NIGHT, Burglary
 6 = 24 Hr (Silent)
 7 = 24 Hr (Audible)
 8 = 24 Hr (Auxiliary)
 9 = FIRE (Fields *35 and *37 only)
 10 = INTERIOR w/DELAY, Burglary (To program, enter # + 10)

- *35 ZONE 5 RESPONSE TYPE [9]
- *36 ZONE 6 RESPONSE TYPE [3]
- *37 ZONE 7 RESPONSE TYPE Console Key B or * & # Panic. Only zone types 0, [6], 7, 8, 9 applicable.
- *38 ENTRY DELAY † 0 = 0 sec; 1 = 20 sec; [2 = 30 sec]; 3 = 45 sec
EXIT Delay = ENTRY Delay + 15 sec

DIALER PROGRAMMING (*40-*49)

- *40 PABX ACCESS CODE Enter 4 digits, 0-9. If fewer than 4 digits entered, exit by pressing * (and press 41, if entering next field). To clear entries from field, press *40*.
- *41 PRIMARY PHONE No. Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing * (and press 42, if entering next field). To clear entries from field, press *41*.
- *42 SECONDARY PHONE No. Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing * (and press 43, if entering next field). To clear entries from field, press *42*.
- *43 SUBSCRIBER ACCOUNT No. Enter 0-9; #+11 for B; #+12 for C; #+13 for D; #+14 for E; #+15 for F. Enter * as 4th digit, if 3+1 dialer reporting is to be used. If only 3 digits used, exit by pressing * (and press 44, if entering next field). To clear entries from field, press *43*.

Examples: For Acct No. 1234, enter: 1 2 3 4
 For Acct No. B234, enter: #+11 2 3 4
 For Acct No. 123, enter: 1 2 3 *

- *44 REPORT FORMAT [0 = 3+1, 4+1 ADEMCO L/S STANDARD] 6 or undefined = 4+2 ADEMCO EXPRESS
 1 = 3+1, 4+1 RADIONICS STANDARD 7 = ADEMCO CONTACT ID REPORTING
 2 = 4+2 ADEMCO L/S STANDARD 8 = 3+1, 4+1 ADEMCO L/S EXPANDED
 3 = 4+2 RADIONICS STANDARD 9 = 3+1, 4+1 RADIONICS EXPANDED

- *45 PHONE SYSTEM SELECT † If Cent. Sta. IS NOT on a WATS line: [0 = Pulse Dial]; 1 = Tone Dial
 If Cent. Sta. IS on a WATS line: 2 = Pulse Dial; 3 = Tone Dial
- *46 SESCOA/RADIONICS SELECT † [0 = Radionics (0-9, B-F reporting)]; 1 = SESCOA (0-9 only reporting)
 Select 0 for all other formats.
- *47 15 SEC DIALER DELAY (BURG) † [0 = no], 1 = yes
- *48 24 HR TEST MESSAGE † [0 = no], 1 = yes (enter Test Code in field *64)

- *49 SPLIT/DUAL REPORTING [0 = Backup report only]

1 = 2 = 3 = 4 = 5 =	TO PRIMARY PHONE No. Alarms, Restore, Cancel All except Open/Close, Test Alarms, Restore, Cancel All except Open, Close, Test All	TO SECONDARY PHONE No. Others Open/Close, Test All All All
---------------------------------	---	--

† Entry of a number other than one specified will give unpredictable results.

OVER →

